

4. Working from the second-row seat of the vehicle carefully manoeuvre the shelf assembly up onto the mounting brackets.
5. Once shelf is in position, install the supplied M6 hardware to secure the shelf in place. See Photo 4 and 5.
6. Ensure all mounting bolts are tightened correctly to complete installation.



ALPINE SERIES STORAGE SHELF

TLR992101



TLR Products
65 Northville Drive
Barnsley NSW 2278



hello@tlrproducts.com.au
www.tlrproducts.com.au



instagram.com/tlrproducts
facebook.com/tlrproducts

SUITED TO:

**TOYOTA PRADO 250 SERIES / LEXUS
GX550**



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 15 minutes.



Spanner
Socket set,
Allen Key set.

FITTING KIT

QUANTITY	PART
1	TLR992101-1 Storage Shelf
1	TLR992101-2 Right-Hand Side Mounting Bracket
1	TLR992101-3 Left-Hand Side Mounting Bracket
2	TLR992101-4 Plastic Corner (Rear)
2	TLR992101-5 Plastic Corner (Front)
8	M5 x 12 Button Head Bolt SS
8	M5 Nyloc Nut SS
4	M6 x 12mm Button Head Bolt SS
4	M6 Nyloc Nuts SS
4	M6 x 12.5mm Flat Washer

NOTE:

This Storage Shelf is part of the Alpine Series Ranger from TLR products and accommodates all Alpine series accessories.

1. Remove both grab handles from the rear cargo area and set aside mounting bolts to re-use shortly. See photo 1.



2. Install the two plastic corners (TLR992101-4) to the rear of the shelf (90-degree angle) and the remaining two plastic corners (TLR992101-5) to the front of the storage shelf using the M5 hardware supplied. See photo 2. *NOTE: If installing the front extension piece (TLR962102) it is not required to install the rear plastic corners (TLR992101-4).*
3. Install both the right and left-hand side mounting brackets as per Photo 3.

